

■ ■ ■ ■ PAVING SOLUTIONS





FULL COLLECTION

QUALITY PAVERS FOR DRIVEWAYS, POOL SURROUNDS, COURT YARDS & PATHS






















CCP has a pavement solution for your next paving project. From small, brick pavers to large format, premium quality concrete pavers and stone alternatives. This contemporary collection of outdoor concrete pavers is available in a range of shapes, sizes and colours.

CCP has pavers to suit every project from DIY commercial and landscape design:

- * Entertaining Areas
- * Driveways
- * Path Stepping Stones
- * Pool Areas
- * Courtyards

CCP provides quality, locally manufactured products.

PAVER RANGE

PRODUCT	COLOURS	RECOMMENDED	Size mm	No. Per M ²	No. Per tonne	No. Per pallet
 Plazzastone	Charcoal Platinum Mocha Pearl Almond Terracotta	  	400x400x50	6.25	60	108
 Flagstone	Charcoal Platinum Mocha Almond	  	300x300x50 + bullnose	11.1	106	192
 Classicstone	Charcoal Mocha Almond	 	220x220x40	20.7	222	400
 Cobblestone	Charcoal Mocha Almond Terracotta	  	230x190x50	23	211	360
 Courtstone	Charcoal Pearl Mocha Almond Sandstone Terracotta Tricolour Ironstone	  	390x195x50	13	127	216
 Brickstone	Charcoal Sandstone Mocha Almond Terracotta	  	200x100x50	50	480	864

Paver images shown in scale 100mm = 10mm



CCP PAVER OPTIONS

PAVER LAYOUT

TERRACOTTA



CHARCOAL



ALMOND



TRICOLOUR



PEARL




MOCHA




PLATINUM




SANDSTONE




Herringbone 45




Stretcher Bond 45




Half Diamond Inlay




Soldier Header




Stack Bond




Basket Weave




Pencil Line Inlay




Stretcher Bond




Diamond



Contrasting Pattern



Stretcher Bond Inlay



Herringbone 90

BEFORE YOU START

1. Check with your council

Pavers can usually be laid around your house without council approval. However, if you're doing a driveway or working in an area where water runoff is an issue, you may need to contact your local council. Some of the newer residential communities have covenants covering the use of driveway material. If so get authorization before proceeding

2. Work out how many pavers you require

- Grab a pencil, paper and tape measure. Measure the length and the width of the area to be paved.
- Then multiply one by the other to determine the total area in square metres. Make an appropriate allowance for curved edges and or cuts.
- Multiply the number of required per m2 by the area to be covered to determine total number of pavers required. Allow an extra 2% just in case.

3. Important Safety

- Always wear eye protection when you're splitting or cutting paver.
- Wear eye protection when you are using a whacker.
- Bend your knees when lifting heavy pavers.
- Wear work boots to protect your feet & gardening gloves to protect your hands.
- Slip, slop, slap if you are working in the sun & keep your fluids up.



CONTACT US

Cnr Young Rd & Ranken Street Cowra NSW 2794

P. 02 6342 1194 F. 02 6342 2937

E. sales@cowraconcreteproducts.com.au

www.cowraconcreteproducts.com.au

Colours displayed in this brochure are to be used as a guide only. Colours are as close as printing processes will allow. Displays in stores may vary to actual colour due to batch variation. Obtain samples from Cowra Concrete Products or current batch colour. Care should be taken to order sufficient product to complete job at one time to avoid batch variation. Surplus pavers are not returnable. No claims after 7 days or once products have been incorporated in construction.

DIY PAVER GUIDE

INSTALLATION GUIDE

Step 1 - EXCAVATION

- Mark out the area to be paved allowing a little extra for working room.
- Remove all loose debris and vegetation.
- Ensure to excavate deep enough to allow for selected paving and sub base construction.

Step 2 - PREPARING BASE

- Distribute road base evenly over the excavated area, making sure to set up with the general fall in mind.
- Compact the road base at least 3 times changing direction during the process.
- Begin to spread the river sand over the compacted road base to a thickness of 25-30mm.
- Screed the river sand with a timber float and straight edge utilising a level to ensure the surface is flat (keeping in mind you will need to allow for water to run off).

Step 3 - LAYING THE PAVERS


- Make sure to set up a header course off along one side to begin, preferably the longest side of the paved area.
- Once this is set up, create a 90° angle at one end of the paved area with a straight edge and set square, then begin to lay the pavers from this point.

Step 4 - EDGING AND LOCKING IN THE PAVING


- Make sure to utilise a sand and cement mix to haunch or lock in the header courses that are not up against a wall. This will assist in supporting the outer course of the paved area.

Handy Tip: It does not hurt to also use a little of the sand and cement underneath the outer header course, as this will create even more strength!


WORKING OUT HOW MANY PAVER YOU NEED



For rectangle areas
eg. $3\text{m} \times 5\text{m} = 15\text{m}^2$



For triangular areas
 $0.5 \times \text{base (m)} \times \text{height (m)}$
= area (m^2)
eg. $0.5 \times 3\text{m} \times 4\text{m} = 6\text{m}^2$



For odd shaped areas

- break into sections

Area 1: $4\text{m} \times 3\text{m} = 12\text{m}^2$

Area 2: $6\text{m} \times 3\text{m} = 18\text{m}^2$

Area 3: $0.5\text{m} \times 2\text{m} \times 6\text{m} = 6\text{m}^2$

Total area to be paved = 36m^2

COWRA CONCRETE PRODUCTS

Cnr Young Rd & Ranken Street Cowra NSW 2794

P. 02 6342 1194 F. 02 6342 2937

E. sales@cowraconcreteproducts.com.au

www.cowraconcreteproducts.com.au

